

Protect What You Love!



Sometimes a plaster can help, but sometimes prevention is better. Rely on Silent Gliss and make your home safer.





The Silent Gliss Child Safety Device makes sure that the chain releases if a child becomes entangled.



All Silent Gliss fabrics are flame retardant. Check out the video and see what this means. www.silentgliss.com/safety


Make it Safe

Silent Gliss offers solutions for maximum safety. This could be the optional Child Safety Device, the flame retardant fabrics or the motorised systems without cords and chains. Ask your dealer for more information and advice.

www.silentgliss.co.uk

www.silentglissglobal.com

WARNING



Young children can be strangled by loops in pull cords, chains, tapes and inner cords that operate the product. To avoid strangulation and entanglement, keep cords out of the reach of young children. Cords may become wrapped around a child's neck. Move beds, cots and furniture away from window covering cords. Do not tie cords together. Make sure cords do not twist and create a loop.

